24 GAGE STEEL RTA BASE CABINET
INSTALL INSTRUCTIONS

NEWAGE PRODUCTS INC.

READ THIS FIRST BEFORE UNPACKING CABINET

ALL CABINETS MUST BE MOUNTED TO STUDS ON A SECURE WALL, AS PER THESE INSTRUCTIONS. FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY AND VOIDS PRODUCT WARRANTY AND MANUFACTURER'S LIABILITY.

WARNING:
DO NOT OVERLOAD CABINETS! CABINETS ARE DESIGNED TO CARRY THE FOLLOWING MAXIMUM WEIGHT CAPACITIES:

Cabinet	Shelf Weight Capacity (lbs)	Overall Weight Capacity
Locker	50	200
Wall	40	80
Base	50	150

PARTS AND HARDWARE SUPPLIED WITH BASE CABINET:

QTY	ITEM	IMAGE
4	Hinge	
47	M5 Frame Screw	
47	M5 Frame Nut	
4	Adjustable Leg	
16	M8 Leg Screws	
16	M8 Leg Screw Nut	
20	M8 Big Washer	
4	Plastic Washer	
16	Lock Washers	
4	2.5" Wall Screw	
4	5/8" Wood Screw	

DO NOT LEAVE CHILDREN UNATTENDED NEAR CABINETS. WHEN FULLY LOADED, CABINETS ARE HEAVY AND THERE IS A RISK OF CABINETS OR ITEMS TIPPING IF IMPROPERLY OPENED.

WARNING:
EXCESSIVE WEIGHT HAZARD

- Use two or more people to move, assemble or install cabinet or locker.
- Failure to do so can result in back or other injury.

UNPACKING OF THE CABINET:

- Begin by placing the cabinet on a sound level surface.
- Remove all cardboard and foam packaging material.
- Remove clear plastic bag.
- Dispose / recycle all packaging materials.
- Remove and verify all the contents in the box. See "Parts and Hardware Supplied List"

24 GAGE STEEL RTA BASE CABINET
INSTALL INSTRUCTIONS

NEWAGE PRODUCTS INC.





A Top Panel

B Bottom Panel

C Left Panel

D Right Panel



E Left Back Panel



F Right Back Panel



G Shelf



H Left Door



I Right Door

24 GAGE STEEL RTA BASE CABINET
INSTALL INSTRUCTIONS

NEWAGE PRODUCTS INC.

1. Use the M5 screw and M5 nut to assemble the two back panels.



2. Assemble the left and right side panel with the same screw and nut. D Goes on the outside of E, and C goes on the outside of F.





3. Panel A sits on the outside of E and F, and on the inside of C and D.



4. Flip the cabinet over. Use M8 screw, washer and M8 nut to assemble the adjustable legs on the bottom panel.



5. Turn the cabinet back upwards, then insert the shelf. If shelf tabs are not catching with the inside of panels D and C, pull the shelf notches outwards.









6. Put the plastic washer in the holes at the four corners.



7. Assemble the right and left doors and insert hinges into the plastic washers. Bend down the clips to fix the hinges in place. Extra spacers are provided to ensure doors are level.



24 GAGE STEEL RTA BASE CABINET
INSTALL INSTRUCTIONS

NEWAGE PRODUCTS INC.

ASSEMBLY INSTRUCTIONS:

INSTALL THE HEIGHT-ADJUSTABLE STEEL LEVELING LEGS:

(for all cabinets except for wall cabinet)

1. Open the cabinet and remove any loose shelves, support brackets, etc.
2. Close / lock the cabinet drawers.
   NOTE: If you need to open the cabinet / locker doors during leveler assembly, open them slowly and do not put any weight on the open doors. This avoids damage to the cabinets hinges.
3. Using two or more people, place the cabinet / locker upside down. Using supplied packaging material to cushion the cabinet to prevent any scratching of the painted surfaces.
4. One at a time line up each height-adjustable leveling legs with the corners of the cabinet. The holes in the base of the cabinet should align with the holes in the adjustable leveling leg.



5. Using the Philips head socket, power drill or hand tighten the bolt with one small Foot Plate washer into each of the holes. There are 4 holes to attach the leveling leg to the base of the cabinets.
   NOTE: Bolts should be snug. Do not over tighten or force bolts. This may result in the damaging of the threads.
   NOTE: When assembling the Locker, Use the 16 smaller washers, not the 4 larger washers to fasten the legs. The 4 larger washers will be used for mounting to the wall, if necessary.



6. Repeat steps 3 – 5 for the remaining legs.
7. Using two or more people, stand up the cabinet and place into desired location.

CABINET LEVELING

(for all cabinets except for wall cabinet)

1. Place a small magnetic level onto the top of the cabinet to verify the levelness of the cabinet.
2. If the floor slopes and the cabinet is not level, lift the adjustable sleeve on the leg and adjust the cabinets height-adjustable leveling leg by turning the nut on top of the cabinet's foot, up or down to bring the cabinet to a level position. This may require two people, one person to verify / bring cabinet level and one person to adjust the legs up and down simultaneously.
3. The cabinet must be adjusted front to back and side to side.
4. Do not put items in the cabinet until the leveling process is complete.

MOUNTING OF THE WORKTOP:

(optional, for base cabinets)

NOTE: Base Cabinet Drawers must be removed prior to mounting Worktop.

- Pull each drawer out to full extension, simultaneously depress the left lock down and right lock up in each slider while pulling out the drawer. The drawer will slide out of the tracks ready to remove. See the diagram to note where the locks are on the drawer slides.



1. Place the Worktop on top of both the base cabinet .
2. Align the Worktop so that it is flush with the side of the base cabinet.
3. Using the supplied Worktop hardware fasten screws through the cabinet top into the Worktop. A cordless power drill is required to drive the screws into the Worktop.



4. Put drawers back into base cabinet by aligning them with the ball-bearing slides drawer tracks. The drawer should slide back into place. Push the drawer fully into the cabinet, then pull it out to full extension. If the drawer does not stop at full extension, or feels loose, the drawer has not been put back into the drawer slides properly. Ensure both drawer slides attached to the drawer are running along the drawer slides attached to the frame of the cabinet.

INSTALLING SHELVES:

NOTE: Plan your shelf heights and install shelves starting from the bottom. The shelves are supported by the metal tabs on the back and side walls of the cabinet.

1. Determine the placement of the shelves.
2. Tilt the shelf so that one end is higher than the other as show in the diagram below.



3. Insert the shelf into the cabinet so that the higher end is directly above the desired slots and push the shelf down into place behind the side slots.
4. Raise the lower end so it is directly above the desired slots and push the shelf down.



24 GAGE STEEL RTA BASE CABINET
INSTALL INSTRUCTIONS

NOTE: Make sure all shelf tabs are completely in place, see below diagram.



5. Repeat steps 2 – 4 for the remaining shelves.

Note: one shelf in the locker must be level with the lock on the door of the cabinet, in order for the lock to work.

MOUNTING CABINETS INTO DRYWALL / STUDDED WALL: WARNING: ALL CABINETS MUST BE MOUNTED TO STUDS BEFORE LOADING THE CABINETS WITH ITEMS

Each locker or base cabinet must be mounted to the wall with at least two of the provided mounting screws. Each wall cabinet must be mounted with four screws.

1. Using a stud finder locate the studs in the wall where the wall cabinet is to be placed.
2. Once studs are located, using a pencil and a level mark a vertical line to indicate stud location.

3. Place the cabinet into position tight against the supporting wall.
4. Open the doors and locate the perforated mounting strip on the top and bottom of the backside of the cabinet.
   Note: the wall cabinet has a perforated strip of holes at the top and bottom of the cabinet, the locker only has a perforated strip at the top of the cabinet.



5. Align the previously marked stud lines with a perforated hole by shifting the cabinet slightly.
6. Place a small magnetic level on top of the wall cabinet and adjust the orientation of the cabinet to bring it to a level position.



7. Once leveled, using the supplied mounting hardware fasten a 2.5" x ¼" cabinet mounting lag bolt with a large washer through the cabinet and into the stud. This can be done by hand with a 7/16th socket wrench or a cordless power drill with a 7/16th socket attachment. Do not over tighten bolts! Once the fender is sitting tightly flush with the backside of the cabinet stop.
8. Repeat Step 6 three additional times with the remaining mounting hardware to install the wall cabinet. You will only repeat this one more time for the locker, as it only has 2 mounting lag bolts.

WALL AND LOCKER CABINET WALL MOUNTING INTO CONCRETE BLOCK / MASONRY WALL:

NOTE: Masonry Hardware **NOT** Included

REQUIRED HARDWARE:

- 2 ¼" x ¼" Tapcon Concrete Anchor (4)

0r

- #10 x 2" Screw with 3/16" masonry plug (4)

1. Place the wall cabinet into position tight against the supporting wall.
2. Open the doors and locate the perforated mounting strip on the top and bottom of the backside of the cabinet.



3. Place a small magnetic level on top of the wall cabinet and adjust the orientation of the cabinet to bring it to a level position.



4. Using a hammer drill, drill 4 pilot holes through the perforated strip in the backside of the cabinet and through the wall.
5. Using either the 2 ¼" x ¼" Tapcon Concrete Anchor or #10 x 2" Screw with 3/16" masonry plug method and the supplied fender washers fasten the cabinet directly to the wall. This application requires a cordless power dill with a #2 Philips bit for ease of installation.
6. Repeat Step 3 - 4 three additional times with the remaining mounting hardware.

THANK YOU for purchasing a Coleman product.
Please give us a call, or visit us online if you have any other questions or comments.

Give us your feedback for a chance to WIN! Take our quick 2 minute survey and enter for your chance to win something FREE from NEWAGE! Visit the website for details at www.newageproducts.com

NEWAGE PRODUCTS INC.
THE ORGANIZED GARAGE

201 Chrislea Road, Vaughan. ON, Canada
1-877-306-8930
www.NEWAGEPRODUCTS.com

NEWAGE PRODUCTS INC. STEEL CABINETRY WARRANTY
1 YEAR LIMITED MANUFACTURER WARRANTY

For one year from the date of purchase, when this product is installed, operated and maintained according to the instructions attached to or furnished with the product, NewAge Products Inc. will replace the defective product or parts if the part fails as a result of defective materials or workmanship.

NEWAGE PRODUCTS INC. WILL NOT PAY FOR:

1. Service calls to correct the installation of any NewAge products or to instruct you how to use or install them.
2. Damage resulting from improper handling or shipping of products, or products damaged by accident, misuse, abuse, fire, flood, improper installation, acts of God, neglect, corrosion, modification or mishandling.
3. Products damaged by improperly loading beyond the specified maximum weight capacity outlined in the instructions provided with the product.
4. Repairs or replacement when your product is used in other than normal, single-family household use, such as a commercial environment, or handled in any way inconsistent with the installation instructions included with the product.
5. Cosmetic damage, including scratches, dings, dents or cracks in paint that do not affect the structural or functional capability of the product.
6. Surfaces damaged due to chemical interaction resulting in corrosion of paint or metal.
7. Replacement parts for NewAge products outside Canada and the United States.
8. Replacement keys or locking mechanisms.
9. Loss of product contents due to left, fire, flood, accident or acts of God.
10. Shipping or freight fees to deliver replacement products or to return defective products.
11. Any labor costs during the limited warranty period.

DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES

IMPLIED WARRANTIES, INCLUDING TO THE EXTENT APPLICABLE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXCLUDED TO THE EXTENT LEGALLY PERMISSIBLE. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO ONE YEAR, OR THE SHORTEST PERIOD ALLOWED BY LAW. SOME STATES AND PROVINCES DO NOT ALLOW LIMITATIONS OR EXCLUSIONS ON HOW LONG AN IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE